



URNS CURLS INTO SMOOTH HAIR IN SECONDS

MEDIDAS DE SEGURIDAD IMPORTANTES

Siempre que use aparatos eléctricos, especialmente en la presencia de niños, debe tomar precauciones básicas de seguridad, entre las cuales las siguientes:

LEA TODAS LAS INSTRUCCIONES ANTES DE USARLO MANTÉNGALO ALEJADO DEL AGUA

PELIGRO - Cualquier aparato enchufado permanece bajo tensión, aunque esté apagado. Para reducir el riesgo de muerte o herida por descarga:

1. **Siempre desconecte el aparato inmediatamente después de usarlo.**
2. No lo use en el baño o la ducha.
3. No coloque ni guarde el aparato donde pueda caer o ser empujado a una bañera o un lavabo.
4. No coloque el aparato ni lo deje caer al agua u otro líquido.
5. Si el aparato cayera al agua, desconéctelo inmediatamente. **No toque el agua.**

ADVERTENCIA - Para reducir el riesgo de quemaduras, electrocución, incendio o heridas:

1. **Nunca deje el aparato desatendido mientras esté conectado.**

TEMP. CONTROL	HAIR TYPE
Low 1-5	Delicate, thin, easy-to-style hair
Medium 6-10	Average to thick or treated hair
Med-High 11-15	Thick or wavy hair
High 16-20	Hard-to-style hair
Maximum 21-30	Very resistant

TEMPERATURE SETTING GUIDE

Within this Instant Heat technology are 30 temperature settings for every type of hair, from the finest to the curliest and most resistant.

UNIFORM HEAT RECOVERY SYSTEM AND TEMPERATURE SETTING

USING INSTANT HEAT, THE 30 30 30

The finely ribbed texture of the housing is designed to gently guide hair as you turn your iron. Ribs hold hair in place when creating more volume or a touch of curl. It's an easy way to add shape to straight styles.

ADD VOLUME AND SHAPE WITH NEW RIBBED TEXTURE HOUSING

One plate of your new flat iron is designed with a little give, to "float" in the iron. This provides better contact with hair and eliminates gaps to achieve straighter results faster.

STYLING WITH THE NEW EASY-GLIDE FLOATING PLATE

15. Lea la información relativa al doble voltaje que se encuentra a continuación antes de enchufar el aparato.

16. El cuerpo del aparato cerca de las placas se vuelve muy caliente durante el uso. No lo toque.

17. No utilice este aparato con un convertidor de voltaje.

GUARDE ESTAS INSTRUCCIONES DE OPERACIÓN

Para uso doméstico solamente. Este aparato ha sido diseñado para funcionar con corriente de 120/240V CA. Utilícelo solamente con corriente alterna (50/60 Hz).

El cable de este aparato está dotado de una clavija polarizada (una pata es más ancha que otra). Como medida de seguridad, se podrá enchufar de una sola manera en la toma de corriente polarizada. Si no entrara en la toma de corriente, inviértela. Si aún no entrara completamente, comuníquese con un electricista. No intente ir en contra de esta función de seguridad.

DOBLE VOLTAJE

Este aparato es biterminio. Se adaptará automáticamente al voltaje adecuado. Puede que sea necesario emplear un adaptador de enchufe (no se incluye) para utilizarlo fuera de los Estados Unidos.

NOTE: Please refer to the temperature setting guide for heat settings.

STYLING WITH NANO BAMBOO CARBON CERAMIC-COATED PLATES

The easy-glide nano bamboo carbon ceramic surface is one of the latest technological advances in hair appliances. Hair glides over the ultra-smooth plate surface as you straighten, and styling product residue removes easily after each use. The unique plate surface creates anti-static smoothing action, helping smooth flyaways and frizzies for high-intensity shine and manageability. Ceramic evenly distributes heat to eliminate hot spots that can damage hair. This advanced new technology leaves hair with a salon-perfect, silky smooth, shiny finish.

Start with a hair section that is 2 inches (5 cm) wide and no more than ½ inch (1.25 cm) thick. Open the iron and place a hair section between the two hot plates, close to the scalp. Trap hair between the plates by firmly squeezing the handles together. While maintaining the tension, slowly pull the iron down along the hair section toward the end. At the end of hair section, release the pressure on the handle and allow the hair to slide out. Repeat process on additional sections of hair until you achieve the hair style you desire. It may be necessary to repeat process on certain areas, depending on the texture of your hair.

FUNDAMENTOS DEL ALISADO
Enchufe el aparato en una toma de corriente de 120/240V. Oprima el botón de encendido/apagado. El indicador luminoso rojo parpadeará hasta que la unidad alcance la temperatura seleccionada. Después, permanecerá encendido. Nunca deje el aparato descendiendo después de encenderlo. Para su seguridad, el aparato se apagará automáticamente después de 60 minutos (con 60 Hz) o 72 minutos (con 50 Hz).

ADVERTENCIA: Las placas se volverán extremadamente calientes en segundos. Evite todo contacto con la piel después de encender el aparato.

Divida el cabello en secciones de 2 pulgadas (5 cm) de ancho por ½ pulgada (1 cm) o menos de espesor. Abra las placas y coloque una sección de cabello entre ellas, cerca del cuero cabelludo. Cierre las placas. Baje la plancha lentamente hasta las puntas, manteniendo las placas bien cerradas. Afloje el cabello tras llegar a las puntas. Repita el proceso con cada sección de cabello. Según la textura del cabello, puede que sea necesario repetir el proceso varias veces en cada sección.

Será necesario experimentar un poco al principio. Con práctica, encontrará la manera perfecta para alisar su cabello fácil y rápidamente.

NOTA: Véase la tabla a continuación para determinar qué nivel de temperatura usar, según el tipo de cabello.

STRAIGHTENING BASICS

Plug the flat iron cord into any household outlet (120/240V). Press ON/OFF button. Red light will blink until it reaches desired temperature setting and then becomes solid. Never leave your flat iron on and unattended. However, should you fail to turn the unit off, it will shut itself off automatically within 60 minutes at 60 Hz (72 minutes at 50 Hz).

DUAL VOLTAGE

This flat iron will automatically adjust to the proper voltage. Use an adapter plug with correct configuration prior to use in outlet.

NOTE: Please refer to the temperature setting guide for heat settings.

This flat iron is intended for household use. This unit is designed to operate at 120/240 volts AC. Use an Alternating Current (50/60 hertz) only. This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

IMPORTANT SAFETY INSTRUCTIONS

REVESTIMIENTO DE NANO BAMBU/ CARBONO/CERÁMICA

Las placas están cubiertas con una capa de nano bambú/carbono/cerámica increíblemente suave, lo último – y lo mejor – en tecnología de aparatos de peluquería. El cabello se desliza fácilmente entre las placas y éstas son muy fáciles de limpiar después de cada uso. La superficie única de las placas tiene una acción suavizante antistática que ayuda a eliminar el frizz, para mayor docilidad y un brillo intenso. La cerámica distribuye el calor uniformemente y evita los daños causados por el mismo. Esta tecnología permite obtener resultados profesionales, sedosos y brillantes.

PLACA FLOTANTE

Esta plancha alisadora está equipada con una placa "flotante" para asegurar un mejor contacto con el cabello y producir resultados más lisos, más rápidamente.

CUERPO CON TEXTURA ACANALADA PARA DAR VOLUMEN

El cuerpo de las placas tiene una textura acanalada que guía el cabello suavemente, creando volumen y rizos suaves. Es una manera fácil de darle forma a cualquier peinado liso.

Y esto no es todo... Su aparato también está dotado de un sistema de conservación del calor, al igual que las herramientas profesionales creadas por los ingenieros de Conair.

A diferencia de otras herramientas cuya temperatura baja durante el uso, este sistema mantiene la temperatura constante, sin pérdida de calor. Cada sección de cabello está peinada usando la misma temperatura, lo que permite obtener resultados uniformes y peinados perfectos.

17. Do not use with a voltage converter.

hot when in use.

16. Do not attempt to touch the housing of your appliance near the straightening plates, as it is hot when in use.

of this manual.

15. Before plugging in, read the information about dual voltage contained in the instruction section of this manual.

appliance.

14. Do not touch hot surfaces of the appliance. Use handles or knobs.

ance.

13. Do not use an extension cord with this appliance.

Keep the air openings free of lint and other debris.

couch, where the air openings may be blocked.

12. Never block the air openings of the appliance or place on a soft surface such as a bed or couch, where the air openings may be blocked.

any surface while it is not or plugged in.

11. **Do not place the heated unit directly on any surface while it is not or plugged in.**

surfaces touch eyes or skin.

10. Unit is hot when in use. Do not let heated surfaces touch eyes or skin.

ing or hose.

8. Never drop or insert any object into any -uedo any

7. Never use while sleeping.

6. Keep the cord away from heated surfaces.

for examination and repair.

damaged, or dropped into water. Return the appliance to the place of purchase or to a qualified service center for examination and repair.

the plug or cord, or if the plug or cord is damaged, do not use the appliance.

properly damaged cord or plug, or if the plug or cord is damaged, do not use the appliance.

5. **Never operate the appliance if it has a damaged cord or plug, or if the plug or cord is damaged, do not use the appliance.**

not recommended by the manufacturer.

4. Use this appliance only if it is intended for use as described in this manual.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

KEEP AWAY FROM WATER

BEFORE USING

READ ALL INSTRUCTIONS

disabilities.

3. This appliance should not be used by, on or near children or individuals with certain disabilities.

appliance, even during storage.

2. **Do not pull, twist, or wrap line cord around appliance, even during storage.**

tended when plugged in.

1. **This appliance should never be left unattended when plugged in.**

electrocution, fire, or injury to persons:

WARNING - To reduce the risk of burns,

immediately. **Do not reach into the water.**

5. If an appliance falls into water, unplug it immediately. **Do not reach into the water.**

fall or be pulled into a tub or sink.

4. Do not place in, or drop into water or other liquids.

3. Do not place or store appliance where it can fall or be pulled into a tub or sink.

2. Do not use while bathing or in a shower.

using.

1. **Always unplug appliance immediately after using.**

of death by electric shock:

even when the switch is off. To reduce the risk

DANGER - Any appliance is electrically live

